





SwitchBoard


Fitting Instructions - Method 2

If using LDE035 Trim and LDM048 End Cap, follow this method.



Parts List:

 QuickClip LDM047	 Starter Clip LDH036	 SwitchBoard LDE033	 Trim & End Cap LDE035 Material: PVCu LDM048 Material: PVCu
---	--	---	--

SwitchBoard's innovative design means it can be installed with either side facing up.




1 Install the skirting onto sub-frame where required.




2 Fit end caps into position using suitable adhesive or using screws either side.

If fixing using screws, all end caps must be installed prior to the fitting of each board.




3 Fix down the first board in position at 600mm (max) centres along the length of the board. See fixing methods below.




If installing SwitchBoard with an overhang (max 25mm), it may be necessary to screw at an increased angle into the sub-frame.


4 Insert QuickClips at 600mm (max) centres along the length of the board and screw in place.



5 Butt the next board up to the clips and secure this board as shown in step 4. Repeat for all remaining boards.



6 Fix down final board in position at 600mm (max) centres along the length of the board. Use methods shown in step 4.



If installing SwitchBoard with an overhang (max 25mm), it may be necessary to screw at an increased angle into the sub-frame.

